

Instruction Manual



30-3706

Mini Flying Lead Harness for Infinity-6/8h



STOP!

THIS PRODUCT HAS LEGAL RESTRICTIONS.
READ THIS BEFORE INSTALLING/USING!

THIS PRODUCT MAY BE USED SOLELY ON VEHICLES USED IN SANCTIONED COMPETITION WHICH MAY NEVER BE USED UPON A PUBLIC ROAD OR HIGHWAY, UNLESS PERMITTED BY SPECIFIC REGULATORY EXEMPTION. (VISIT THE "EMISSIONS" PAGE AT [HTTP://WWW.SEMASAN.COM/EMISSIONS](http://www.semasan.com/EMISSIONS) FOR STATE BY STATE DETAILS.)

IT IS THE RESPONSIBILITY OF THE INSTALLER AND/OR USER OF THIS PRODUCT TO ENSURE THAT IT IS USED IN COMPLIANCE WITH ALL APPLICABLE LAWS AND REGULATIONS. IF THIS PRODUCT WAS PURCHASED IN ERROR, DO NOT INSTALL AND/OR USE IT. THE PURCHASER MUST ARRANGE TO RETURN THE PRODUCT FOR A FULL REFUND.

THIS POLICY ONLY APPLIES TO INSTALLERS AND/OR USERS WHO ARE LOCATED IN THE UNITED STATES; HOWEVER CUSTOMERS WHO RESIDE IN OTHER COUNTRIES SHOULD ACT IN ACCORDANCE WITH THEIR LOCAL LAWS AND REGULATIONS.

WARNING: This installation is not for the tuning novice! Use this system with **EXTREME** caution! The AEM Infinity Programmable EMS allows for total flexibility in engine tuning. Misuse or improper tuning of this product can destroy your engine! If you are not well versed in engine dynamics and the tuning of engine management systems **DO NOT** attempt the installation. Refer the installation to an AEM-trained tuning shop or call 800-423-0046 for technical assistance.

NOTE: All supplied AEM calibrations, Wizards and other tuning information are offered as potential starting points only. **IT IS THE RESPONSIBILITY OF THE ENGINE TUNER TO ULTIMATELY CONFIRM IF THE CALIBRATION IS SAFE FOR ITS INTENDED USE.** AEM holds no responsibility for any engine damage that results from the misuse or mistuning of this product!

AEM Performance Electronics
AEM Performance Electronics, 2205 126th Street Unit A, Hawthorne, CA 90250
Phone: (310) 484-2322 Fax: (310) 484-0152
<http://www.aemelectronics.com>
Instruction Part Number: 10-3706
Document Build 10/29/2015

Introduction

Some harness user manuals contain active hyperlinks that point to specific sections or even launch additional documents such as wiring diagrams. Recommend viewing this document electronically to take advantage of all features.

Several universal wiring harness options are available for Infinity products. They range in complexity from simple plug and pin kits to complete engine harness assemblies that include power distribution centers. Custom wiring harness projects should only be undertaken by experienced harness builders. If in doubt, please contact AEM for recommendations.

30-3805 Universal V8 harness system for Infinity-8/10 systems

The Infinity Universal V8 Harness system consists of a universal core harness and optional application specific extensions. It was designed with flexibility in mind. The harness system includes many features and it can be used in many different applications.

30-3809 Universal V8 harness system for Infinity-6/8h systems

The Infinity Universal V8 Harness system consists of a universal core harness and optional application specific extensions. It was designed with flexibility in mind. It includes throttle body and pedal interfaces for DBW applications. The harness system includes many features and it can be used in many different applications.

30-3705 Universal Mini Harness for Infinity-6/8h systems

This harness is intended to be used as a starting point by experienced harness builders. It saves time by including basic power distribution features that can be expanded to suit many application requirements. It allows the harness builder to populate the ECU connector with only the features needed by the application.

30-3706 Mini Flying Lead Harness for Infinity-6/8h systems

This harness is intended to be used as a starting point by experienced harness builders. It saves time by including flying leads that can be terminated by the harness builder at the sensor and actuator connectors.

30-3702 Infinity-8/10/12 Mini-harness

This harness is intended to be used as a starting point by experienced harness builders. It saves time by including basic power distribution features that can be expanded to suit many application requirements. It allows the harness builder to populate the ECU connector with only the features needed by the application. Includes 100 96" pre-terminated leads.

30-3703 Infinity-8/10/12 Mini-harness

This harness is intended to be used as a starting point by experienced harness builders. It saves time by including basic power distribution features that can be expanded to suit many application requirements. It allows the harness builder to populate the ECU connector with only the features needed by the application.

30-3701 Infinity-8/10/12 Plug & Pin Kit

Bare necessities to begin a custom wire harness design. Includes 73 and 56 pin Molex MX123 harness connectors, terminals and sealing plugs, main relay and relay socket.

30-3704 Infinity-6/8h Plug & Pin Kit

Bare necessities to begin a custom wire harness design. Includes 80 pin Molex MX123 harness connector, terminals and sealing plugs, main relay and relay socket.

Please read the entire User Manual prior to beginning any installation.

3706 Kit Contents

AEM P/N	Description	Qty
36-3706	Mini Flying Lead Harness	1
35-2060	Micro Relay	1
3706-001	22ga Wire with Molex Terminal, 96"	10
3706-002	Cable 2-Pair Twisted/Shielded, 96"	2
4-2000	Terminal, Molex 22ga	40



ECU Connectors

The Infinity-6/8h/8/10 ECUs use the MX123 Sealed Connection System from Molex. AEM strongly recommends that users become familiar with the proper tools and procedures before attempting any modifications or additions to these connector housings. The entire Molex user manual can be downloaded direct from Molex at http://www.molex.com/mx_upload/family/MX123UserManual.pdf

Installation Notes

Wiring Conventions and EMI

Some wire harness assemblies come pre-wired with all connectors, fuses, and relays needed to operate an engine. Harnesses that include a PDC generally require extension/termination of the flying leads to their appropriate devices, and additional sensors and other devices can be wired into the harness as needed for the specific application. The following guidelines should be adhered to while completing the required wiring.

A proper wiring job includes proper termination of the wire at the sensor. The wire terminal end must be moisture tight where it plugs into the sensor and it must have strong, electrically sound terminals. The preferred method of

securing a wire to a terminal is to use a crimp terminal with NO solder. It is important to use the proper crimping tool for sound terminal construction. Plastic terminal plugs must have moisture tight seals. Inspect each plug to make sure the seals are in place. Di-electric grease can be added in the terminal slots to further aid in corrosion resistance.

If a splice into a wire must be made and no solder-less terminals are available, then you must properly solder the splice.

Noise can be a serious problem and can cause intermittent misfiring of the engine. Every precaution should be taken to prevent interference to the ECU's operation. Resistive plug leads are REQUIRED.

To eliminate or reduce the chance of EMI, wires that carry high current must run in twisted pairs. An example of this would be the power leads from a multiple spark ignition system. These ignition systems can carry up to 100 amps for a couple milliseconds at the time of discharge, which induces a strong magnetic field in close proximity of the wires.

The routing of the wire loom is critical to EFI system performance and safety. The following safety considerations should be made when installing the wire loom:

- Heat protection: the loom should be placed away from or insulated from sources of heat. The obvious item(s) that should be avoided are the exhaust manifolds, EGR delivery tubes, and turbochargers. If it is absolutely necessary to route a wire in close proximity to any of these items, then a suitable insulator must be used.
- Noise suppression: do not route wires near the HT leads. For coil-on-plug ignition systems this is not as critical.
- Moving component protection: route wires away from moving components such as fans, the blower belt, or the throttle linkage. Also, make sure the wires are not under any strain when the engine is at full deflection on the motor mounts.
- Never have the wires in exposed bundles throughout the engine compartment.

Determining ECU Location

- It is recommended that the ECU be placed in an environment that does not expose it to temperatures above 85° Celsius (160F).
- In cases where the Infinity is to be used in place of the stock ECU, the location that the stock ECU occupied is suitable.
- On applications where the ECU is to be located in a different position than stock, the interior of the vehicle is best.
- The Infinity should be located in a place that reduces the length of extension wires from the PDC while maintaining an environmentally sound location.
- The ECU location must permit the PDC to be mounted in a serviceable location.

Power Distribution Center

PDCs included in the harness assemblies generally include all relays and fuses necessary for proper function and should be mounted in a location which permits serviceability. Ideally the PDC should be located in the passenger compartment, or if necessary within the engine compartment as far away from heat sources as can be achieved. Some PDCs contain flying lead bundles which must be wired to the battery, fuel pump and radiator fan(s), switched ignition and possibly other interfaces. Routing of this flying lead bundle should also be taken into account when determining the mounting location of the PDC.

3706 Installation Tips

The Mini Flying Lead Harness comes bundled into several groups for ease of location and identification. Each wire within a bundle is printed with the wire's function 6" from the end.

NOTE: This harness includes wires labeled for Injectors 7 & 8 and Coils 7 & 8. These outputs are only available on Infinity-308 (formerly Infinity-8h) ECUs, and are not present on the Infinity-306 (formerly Infinity-6). These wires are noted with an asterisk (*) in the tables below. In the case of using this harness with an Infinity-306 ECU, the unused flying leads may be re-purposed for the corresponding ECU I/O. Refer to ECU pinout documentation for details. Any unused wires should either be removed from the harness, or insulated and secured out of the way.

A Micro Relay is included in this harness kit to control power to the ECU. The relay needs to be installed into the holder located next to the main ECU connector on the wire harness. The relay will only fit in the holder in one direction.



3706 Flying Lead Harness Pinouts

Pin	Infinity Connector C1			80 Way F Receptacle 0.64 2.8 Series Sealed (GY)
	Wire Color	Gauge	Destination	Function
C1-1				
C1-2	PNK	22	Main I/O Bundle	TACH (Lowside 5)
C1-3	ORG	22	Injector Bundle	INJECTOR 7*
C1-4	ORG	22	Injector Bundle	INJECTOR 8*
C1-5	YEL	20	UEGO Sensor Connector- Pin 4	UEGO1 HEAT
C1-6	YEL	20	UEGO Sensor Connector- Pin 2	UEGO1 IA
C1-7	YEL	20	UEGO Sensor Connector- Pin 6	UEGO 1 IP
C1-8	YEL	20	UEGO Sensor Connector- Pin 1	UEGO 1 UN
C1-9	YEL	20	UEGO Sensor Connector- Pin 5	UEGO1 VM
C1-10	RED	18	PWR-3	PERM BATTERY PWR
C1-11	BLU	22	Coil Bundle	COIL 4
C1-12	BLU	22	Coil Bundle	COIL 3
C1-13	BLU	22	Coil Bundle	COIL 2
C1-14	BLU	22	Coil Bundle	COIL 1
C1-15	BLU	22	Coil Bundle	COIL 6
C1-16	BLU	22	Coil Bundle	COIL 5
C1-17				
C1-18				
C1-19				
C1-20				
C1-21	PNK	22	Main I/O Bundle	FAN (Lowside 2)
C1-22				
C1-23	BLK	22	Main I/O Bundle	SIG GND (ANALOG SENSOR GROUND)
C1-24				
C1-25				
C1-26				
C1-27				
C1-28				
C1-29				
C1-30	TAN	22	Main I/O Bundle	2 STEP (Digital 5)
C1-31	BLU	22	Coil Bundle	COIL 7*

C1-32	BLU	22	Coil Bundle	COIL 8*
C1-33	BLK	18	S1	BATTERY GROUND
C1-34				
C1-35				
C1-36				
C1-37				
C1-38	WHT	22	Main I/O Bundle	CLT TEMP
C1-39	WHT	22	Main I/O Bundle	AIR TEMP
C1-40				
C1-41	PNK	22	Main I/O Bundle	FUEL PUMP (Lowside 0)
C1-42				
C1-43	BLK	18	GND-2	BATTERY GROUND
C1-44				
C1-45				
C1-46	BLK	18	GND-3	BATTERY GROUND
C1-47	RED	22	R-85	RELAY CONTROL OUT
C1-48	RED	22	Ignition Switch Lead	IGN SWITCH IN
C1-49	RED	22	Main I/O Bundle	VCC (ANALOG SENSOR POWER +5V)
C1-50				
C1-51	WHT	22	Main I/O Bundle	TPS
C1-52	WHT	22	Main I/O Bundle	MAP
C1-53				
C1-54				
C1-55				
C1-56				
C1-57				
C1-58				
C1-59				
C1-60				
C1-61				
C1-62				
C1-63	RED	22	R-87	RELAY POWER IN 12V
C1-64	ORG	22	Injector Bundle	INJECTOR 6
C1-65	ORG	22	Injector Bundle	INJECTOR 5
C1-66	ORG	22	Injector Bundle	INJECTOR 4
C1-67	BLK	18	GND-4	BATTERY GROUND
C1-68	RED	22	R-87	RELAY POWER IN 12V
C1-69				

C1-70				
C1-71				
C1-72				
C1-73				
C1-74				
C1-75				
C1-76	ORG	22	Injector Bundle	INJECTOR 3
C1-77	ORG	22	Injector Bundle	INJECTOR 2
C1-78	ORG	22	Injector Bundle	INJECTOR 1
C1-79				
C1-80				

Injector Bundle

	Wire Color	Gauge	Destination	Wire Marking	Connection
	ORG	22	C1-78	INJ1	Cylinder 1 Injector Signal
	ORG	22	C1-77	INJ2	Cylinder 2 Injector Signal
	ORG	22	C1-76	INJ3	Cylinder 3 Injector Signal
	ORG	22	C1-66	INJ4	Cylinder 4 Injector Signal
	ORG	22	C1-65	INJ5	Cylinder 5 Injector Signal
	ORG	22	C1-64	INJ6	Cylinder 6 Injector Signal
	ORG	22	C1-3	INJ7*	Cylinder 7 Injector Signal (Infinity-308 only)
	ORG	22	C1-4	INJ8*	Cylinder 8 Injector Signal (Infinity-308 only)

Coil Bundle

	Wire Color	Gauge	Destination	Wire Marking	Connection
	BLU	22	C1-14	COIL 1	Cylinder 1 Coil Signal 0-5V Falling Edge Trigger
	BLU	22	C1-13	COIL 2	Cylinder 2 Coil Signal 0-5V Falling Edge Trigger
	BLU	22	C1-12	COIL 3	Cylinder 3 Coil Signal 0-5V Falling Edge Trigger
	BLU	22	C1-11	COIL 4	Cylinder 4 Coil Signal 0-5V Falling Edge Trigger
	BLU	22	C1-16	COIL 5	Cylinder 5 Coil Signal 0-5V Falling Edge Trigger
	BLU	22	C1-15	COIL 6	Cylinder 6 Coil Signal 0-5V Falling Edge Trigger
	BLU	22	C1-31	COIL 7*	Cylinder 7 Coil Signal 0-5V Falling Edge Trigger (Infinity-308 only)
	BLU	22	C1-32	COIL 8*	Cylinder 8 Coil Signal 0-5V Falling Edge Trigger (Infinity-308 only)

Ignition Switch Lead

	Wire Color	Gauge	Destination	Wire Marking	Connection
	RED	22	C1-48	IGN SW	Connect to single terminal on the ignition switch that provides +12V when the key is in both the 'Start' (cranking) and 'Run' position.

UEGO Sensor Connector

	Wire Color	Gauge	Destination	
	YEL	20	C1-8	Plugs into AEM p/n 30-2001 Bosch LSU 4.2 Wideband UEGO Sensor
	YEL	20	C1-6	
	YEL	20	AFR VH+	
	YEL	20	C1-5	
	YEL	20	C1-9	
	YEL	20	C1-7	

Main I/O Bundle

	Wire Color	Gauge	Destination	Wire Marking	Connection
	WHT	22	C1-51	TPS	Throttle Position signal
	WHT	22	C1-52	MAP	Manifold Absolute Pressure signal
	WHT	22	C1-38	CLT TEMP	Coolant Temp Sensor signal
	WHT	22	C1-39	AIR TEMP	Air Temp Sensor signal
	RED	22	C1-49	VCC	+5V Supply for 0-5V Analog Sensors (TPS, MAP)
	BLK	22	C1-23	SIG GND	Sensor Ground Reference for Analog and Temperature Sensors (TPS, MAP, CLT, IAT)
	PNK	22	C1-21	FAN	Lowside (Ground) trigger for cooling fan relay
	PNK	22	C1-2	TACH	12V square wave signal for tachometer
	PNK	22	C1-41	FUEL PUMP	Lowside (Ground) trigger for fuel pump relay
	TAN	22	C1-30	2 STEP	Switched input to trigger 2-Step rev limiter or other function. Ground this wire to trigger input.

Power/Ground Bundle

	Wire Color	Gauge	Destination	Wire Marking	Connection
--	------------	-------	-------------	--------------	------------

	RED	18	R-30	BATT+	Connect to battery positive (+) terminal.
	RED	18	R-86	BATT+	
	RED	18	C1-10	PERM	
	YEL	20	UEGO Sensor Connector- Pin 3	AFR VH+	Connect to ignition-switched +12V power source. Do <u>not</u> connect to constant power source.
	BLK	18	C1-33	PWR GND	Connect to chassis ground. Remove paint or plating at the attachment point. In general, the the resistance from the battery ground to this chassis location should be less than 0.1 Ohm.
	BLK	18	C1-43	PWR GND2	
	BLK	18	C1-46	PWR GND3	
	BLK	18	C1-67	GROUND	

ECU Relay

Pin	Wire Color	Gauge	Destination	Description
R-85	RED	22	C1-47	ECU RELAY CONTROL SIGNAL
R-86	RED	18	Power/Ground Bundle BATT+	BATT+
R-87	RED	22	C1-63	+12V RELAY POWER TO ECU
R-30	RED	18	Power/Ground Bundle BATT+	BATT+
R-87A				

Infinity-6/8h ECU Pinout

Infinity Pin	Hardware Ref.	Hardware Specification	Notes
C1-1	Lowside 4	Lowside switch, 1.7A max, NO internal flyback diode. 12V pullup	See Setup Wizard Page "Output Function Assignment" for setup options.
C1-2	Lowside 5	Lowside switch, 6A max with internal flyback diode. Inductive load should NOT have full time power. 12V pullup	See Setup Wizard Page "Output Function Assignment" for setup options.
C1-3*	Lowside 6 (*Infinity-6 Only)	Lowside switch, 6A max with internal flyback diode. Inductive load should NOT have full time power. No pullup	See Setup Wizard Page "Output Function Assignment" for setup options.
C1-3**	Injector 7 (**Infinity-8H Only)	For use with high impedance (10-15 ohms) injectors only,	Available on P/N 30-7108 only

Infinity Pin	Hardware Ref.	Hardware Specification	Notes
		1.7A max.	
C1-4*	Lowside 7 (*Infinity-6 Only)	Lowside switch, 6A max, NO internal flyback diode. No pullup	See Setup Wizard Page "Output Function Assignment" for setup options.
C1-4**	Injector 8 (**Infinity-8H Only)	For use with high impedance (10-15 ohms) injectors only, 1.7A max.	Available on P/N 30-7108 only
C1-5	UEGO 1 Heat	Bosch UEGO controller	Lowside switch for UEGO heater control. Connect to pin 4 of Bosch UEGO sensor. NOTE that pin 3 of the Sensor is heater (+) and must be power by a fused/switched 12V supply.
C1-6	UEGO 1 IA		Trim Current signal. Connect to pin 2 of Bosch UEGO sensor
C1-7	UEGO 1 IP		Pumping Current signal. Connect to pin 6 of Bosch UEGO sensor
C1-8	UEGO 1 UN		Nernst Voltage signal. Connect to pin 1 of Bosch UEGO sensor
C1-9	UEGO 1 VM		Virtual Ground signal. Connect to pin 5 of Bosch UEGO sensor.
C1-10	Battery Perm Power	Dedicated power management CPU	Full time battery power. MUST be powered before the ignition switch input is triggered (See C1-48).
C1-11	Coil 4	25 mA max source current	0-5V Falling edge fire. DO NOT connect directly to coil primary. Must use an ignitor OR CDI that accepts a FALLING edge fire signal.
C1-12	Coil 3	25 mA max source current	0-5V Falling edge fire. DO NOT connect directly to coil primary. Must use an ignitor OR CDI that accepts a FALLING edge fire signal.
C1-13	Coil 2	25 mA max source current	0-5V Falling edge fire. DO NOT connect directly to coil primary. Must use an ignitor OR CDI that accepts a FALLING edge fire signal.
C1-14	Coil 1	25 mA max source current	0-5V Falling edge fire. DO NOT connect directly to coil primary. Must use an ignitor OR CDI that accepts a FALLING edge fire signal.
C1-15	Coil 6	25 mA max source current	0-5V Falling edge fire. DO NOT connect directly to coil primary. Must use an ignitor OR CDI that accepts a FALLING edge fire signal.

Infinity Pin	Hardware Ref.	Hardware Specification	Notes
C1-16	Coil 5	25 mA max source current	0-5V Falling edge fire. DO NOT connect directly to coil primary. Must use an ignitor OR CDI that accepts a FALLING edge fire signal.
C1-17	Crankshaft Position Sensor VR+	Differential Variable Reluctance Zero Cross Detection	See Setup Wizard page Cam/Crank for options.
C1-18	Crankshaft Position Sensor VR-		See Setup Wizard page Cam/Crank for options.
C1-19	Camshaft Position Sensor 1 VR-	Differential Variable Reluctance Zero Cross Detection	See Setup Wizard page Cam/Crank for options.
C1-20	Camshaft Position Sensor 1 VR+		See Setup Wizard page Cam/Crank for options.
C1-21	Lowside 2	Lowside switch, 1.7A max, NO internal flyback diode. No pullup	See Setup Wizard Page "Output Function Assignment" for setup options.
C1-22	Lowside 3	Lowside switch, 6A max with internal flyback diode. Inductive load should NOT have full time power. No pullup	See Setup Wizard Page "Output Function Assignment" for setup options.
C1-23	Analog Sensor Ground	Dedicated analog ground	Analog 0-5V sensor ground
C1-24	Analog Sensor Ground	Dedicated analog ground	Analog 0-5V sensor ground
C1-25	Crankshaft Position Sensor Hall	10K pullup to 12V. Will work with ground or floating switches.	See Setup Wizard page Cam/Crank for options.
C1-26	Camshaft Position Sensor 1 Hall	10K pullup to 12V. Will work with ground or floating switches.	See Setup Wizard page Cam/Crank for options.
C1-27	Digital 2	10K pullup to 12V. Will work with ground or floating switches.	See Setup Wizard page Cam/Crank for options.
C1-28	Dig3 [Hz] / Dig3 Duty	10K pullup to 12V. Will work with ground or floating switches.	See Setup Wizard page "Input Function Assignments" for setup options.
C1-29	Dig4 [Hz] / Dig4 Duty	10K pullup to 12V. Will work with ground or floating switches.	See Setup Wizard page "Input Function Assignments" for setup options.
C1-29	RS232 Rx	RS232 Line Driver/Receiver	Future expansion
C1-30	Digital 5	10K pullup to 12V. Will work with ground or floating switches.	See Setup Wizard page "Input Function Assignments" for setup options.


Infinity Pin	Hardware Ref.	Hardware Specification	Notes
			options.
C1-30	RS232 Tx	RS232 Line Driver/Receiver	Future expansion
C1-31*	Dig6 [Hz] / Dig6_Duty (*Infinity-6 Only)	10K pullup to 12V. Will work with ground or floating switches.	See Setup Wizard page "Input Function Assignments" for setup options.
C1-31**	Coil 7 (**Infinity-8H Only)	25 mA max source current	Available on P/N 30-7108 only. 0-5V Falling edge fire. DO NOT connect directly to coil primary. Must use an ignitor OR CDI that accepts a FALLING edge fire signal.
C1-32*	Digital 7 (*Infinity-6 Only)	10K pullup to 12V. Will work with ground or floating switches.	See Setup Wizard page "Input Function Assignments" for setup options.
C1-32**	Coil 8 (**Infinity-8H Only)	25 mA max source current	Available on P/N 30-7108 only. 0-5V Falling edge fire. DO NOT connect directly to coil primary. Must use an ignitor OR CDI that accepts a FALLING edge fire signal.
C1-33	Battery Ground	Battery Ground	Connect directly to battery ground
C1-34	CANL A	Dedicated High Speed CAN Transceiver	Recommend twisted pair (one twist per 2") with terminating resistor. Contact AEM for additional information.
C1-35	CANH A	Dedicated High Speed CAN Transceiver	Recommend twisted pair (one twist per 2") with terminating resistor. Contact AEM for additional information.
C1-36	CanL B	Dedicated High Speed CAN Transceiver	Not used, reserved for future expansion.
C1-37	CanH B	Dedicated High Speed CAN Transceiver	Not used, reserved for future expansion.
C1-38	Analog Temp 1	12 bit A/D, 2.49K pullup to 5V	Default Coolant Temperature Input
C1-39	Analog Temp 2	12 bit A/D, 2.49K pullup to 5V	Default Air Temperature Input
C1-40	Analog Temp 3	12 bit A/D, 2.49K pullup to 5V	Default Oil Temperature Input. See Setup Wizard page "Input Function Assignments" for setup options.
C1-41	Lowside 0	Lowside switch, 1.7A max, NO internal flyback diode. No pullup	See Setup Wizard Page "Output Function Assignment" for setup options.
C1-42	Lowside 1	Lowside switch, 6A max with internal flyback diode. Inductive	See Setup Wizard Page "Output Function Assignment" for setup

Infinity Pin	Hardware Ref.	Hardware Specification	Notes
		load should NOT have full time power. No pullup	options.
C1-43	Battery Ground	Battery Ground	Connect directly to battery ground
C1-44	Knock Sensor 1	Dedicated knock signal processor	See Setup Wizard page Knock Setup for options.
C1-45	Knock Sensor 2	Dedicated knock signal processor	See Setup Wizard page Knock Setup for options.
C1-46	Battery Ground	Battery Ground	Connect directly to battery ground
C1-47	EFI Main Relay Switched Ground Output	0.7A max ground sink for external relay control	Will activate at key on and at key off according to the configuration settings.
C1-48	Ignition Switch	10K pulldown	Full time battery power must be available at C1-10 before this input is triggered.
C1-49	+5V Sensor Power	Regulated, fused +5V supply for sensor power	Analog sensor power
C1-50	+5V Sensor Power	Regulated, fused +5V supply for sensor power	Analog sensor power
C1-51	Analog 7	12 bit A/D, 100K pullup to 5V	Default primary Throttle Position sensor input. 0-5V analog signal. Use +5V Out pins as power supply and Sensor Ground pins as the low reference. Do not connect signals referenced to +12V as this can permanently damage the ECU. See Setup Wizard Set Throttle Range page for automatic min/max calibration. Monitor the Throttle [%] channel. Also DB1_TPSA [%] for DBW applications.
C1-52	Analog 8	12 bit A/D, 100K pullup to 5V	Default Manifold Pressure Sensor input. 0-5V analog signal. Use +5V Out pins as power supply and Sensor Ground pins as the low reference. Do not connect signals referenced to +12V as this can permanently damage the ECU.

Infinity Pin	Hardware Ref.	Hardware Specification	Notes
C1-53	Analog 9	12 bit A/D, 100K pullup to 5V	Default Fuel Pressure Sensor Input. 0-5V analog signal. Use +5V Out pins as power supply and Sensor Ground pins as the low reference. Do not connect signals referenced to +12V as this can permanently damage the ECU.
C1-54	VR+ 2	Differential Variable Reluctance Zero Cross Detection	See Setup Wizard page "Input Function Assignments" for setup options.
C1-55	VR- 2		
C1-56	VR- 3	Differential Variable Reluctance Zero Cross Detection	See Setup Wizard page "Input Function Assignments" for setup options.
C1-57	VR+ 3		
C1-58	Highside 0	2.6A max, High Side Solid State Relay	See Setup Wizard Page "Output Function Assignment" for setup options.
C1-59	Stepper 1B	Automotive, Programmable Stepper Driver, up to 28V and $\pm 1.4A$	Be sure that each internal coil of the stepper motor are properly paired with the 1A/1B and 2A/2B ECU outputs. Supports Bi-Polar stepper motors only.
C1-60	Stepper 2B	Automotive, Programmable Stepper Driver, up to 28V and $\pm 1.4A$	Be sure that each internal coil of the stepper motor are properly paired with the 1A/1B and 2A/2B ECU outputs. Supports Bi-Polar stepper motors only.
C1-61	DBW1 Motor -	5.0A max Throttle Control Hbridge Drive	+12V to close
C1-62	DBW1 Motor +	5.0A max Throttle Control Hbridge Drive	+12V to open
C1-63	Main Relay Power Input	12 volt power from relay	12 volt power from relay. Relay must be controlled by +12V Relay Control signal, pin C1-47 above.
C1-64	Injector 6	Saturated (P/N 30-7108) or peak and hold, 3A max continuous (P/N 30-7106)	Injector 6
C1-65	Injector 5	Saturated (P/N 30-7108) or peak and hold, 3A max continuous (P/N 30-7106)	Injector 5
C1-66	Injector 4	Saturated (P/N 30-7108) or peak and hold, 3A max continuous (P/N 30-7106)	Injector 4

Infinity Pin	Hardware Ref.	Hardware Specification	Notes
C1-67	Battery Ground	Battery Ground	Connect directly to battery ground
C1-68	Main Relay Power Input	12 volt power from relay	12 volt power from relay. Relay must be controlled by +12V Relay Control signal, pin C1-47 above.
C1-69	Analog 19	12 bit A/D, 100K pullup to 5V	0-5V analog signal. Use +5V Out pins as power supply and Sensor Ground pins as the low reference. Do not connect signals referenced to +12V as this can permanently damage the ECU. See Setup Wizard page "Input Function Assignments" for setup options.
C1-70	Analog 18	12 bit A/D, 100K pullup to 5V	0-5V analog signal. Use +5V Out pins as power supply and Sensor Ground pins as the low reference. Do not connect signals referenced to +12V as this can permanently damage the ECU. See Setup Wizard page "Input Function Assignments" for setup options.
C1-71	Analog 16	12 bit A/D, 100K pullup to 5V	0-5V analog signal. Use +5V Out pins as power supply and Sensor Ground pins as the low reference. Do not connect signals referenced to +12V as this can permanently damage the ECU. See Setup Wizard page "Input Function Assignments" for setup options.
C1-72	Flash Enable	10K pulldown	Not usually needed for automatic firmware updates through Infinity Tuner. If connection errors occur during update, connect 12 volts to this pin before proceeding with upgrade. Disconnect the 12 volts signal after the update.
C1-73	Analog 13	12 bit A/D, 100K pullup to 5V	Default Oil Pressure Sensor input. 0-5V analog signal. Use +5V Out pins as power supply and Sensor Ground pins as the low reference. Do not connect signals referenced to +12V as this can permanently damage the ECU.
C1-74	Analog 11	12 bit A/D, 100K pullup to 5V	0-5V analog signal. Use +5V Out pins as power supply and Sensor Ground


Infinity Pin	Hardware Ref.	Hardware Specification	Notes
			pins as the low reference. Do not connect signals referenced to +12V as this can permanently damage the ECU. See Setup Wizard page "Input Function Assignments" for setup options.
C1-75	Analog 10	12 bit A/D, 100K pullup to 5V	0-5V analog signal. Use +5V Out pins as power supply and Sensor Ground pins as the low reference. Do not connect signals referenced to +12V as this can permanently damage the ECU. See Setup Wizard page "Input Function Assignments" for setup options.
C1-76	Injector 3	Saturated (P/N 30-7108) or peak and hold, 3A max continuous (P/N 30-7106)	Injector 3
C1-77	Injector 2	Saturated (P/N 30-7108) or peak and hold, 3A max continuous (P/N 30-7106)	Injector 2
C1-78	Injector 1	Saturated (P/N 30-7108) or peak and hold, 3A max continuous (P/N 30-7106)	Injector 1
C1-79	Stepper 2A	Automotive, Programmable Stepper Driver, up to 28V and $\pm 1.4A$	Be sure that each internal coil of the stepper motor are properly paired with the 1A/1B and 2A/2B ECU outputs. Supports Bi-Polar stepper motors only.
C1-80	Stepper 1A	Automotive, Programmable Stepper Driver, up to 28V and $\pm 1.4A$	Be sure that each internal coil of the stepper motor are properly paired with the 1A/1B and 2A/2B ECU outputs. Supports Bi-Polar stepper motors only.




INFINITY "C1" 80 PIN

Power Distribution, Infinity-6/8h

NAME	FUNCTION
GND	Battery ground
PERM	Fused connection to battery positive terminal (+12V, always hot)
IGN SW	Fused connection to vehicle ignition switch (+12V in RUN/CRANK only)
RELAY	Switched ground from ECU connected to relay coil primary negative
+12V	Relay driven +12V power source for ECU power and auxiliary outputs
+5V Reference	+5V supplied by ECU
Sensor Ground	Analog ground used as ground point for sensors



INFINITY "C1" 80 PIN



NOTES:
 VERY IMPORTANT
 ALL user installed auxiliary relays must be powered by the output from the EFI main relay.
 All user installed auxiliary circuits should be protected with a properly sized fuse as shown.
 Relays with internal diodes must have the anode side of the coil connected to the ECU.



Drawing: Power Distribution


ECU: Infinity-6/8h

Date: 08/05/2014

Rev: A

Engineer: Nakano

95 BMW E36 M3, Infinity-6/8h



Drawing: 1995 BMW M3 E36 M50


ECU: Infinity-6/8h

Date: 02/20/2014

Rev: A

Engineer: Nakano

EVO VIII, Infinity-6/8h



Drawing: 2003-05 Mitsubishi EVO VIII


ECU: Infinity-6/8h

Date: 02/19/2014

Rev: A

Engineer: Nakano

EVO IX Pinout, Infinity-6/8h



Drawing: 2006 Mitsubishi EVO IX


ECU: Infinity-6/8h

Date: 02/20/2014

Rev: A

Engineer: Nakano

93-98 Toyota Supra 2JZGTE, Infinity-6/8h



Drawing: 1993-98 Toyota Supra 2JZGTE



ECU: Infinity-6/8h

Date: 02/24/2014

Rev: A

Engineer: Nakano

Ignition System – COP 2 Wire "Dumb" Coils with Ignitor, Infinity-6/8h



INFINITY "C1" 80 PIN

NOTES:
 Coils are to be wired by cylinder #
 Coil 1 - Cylinder 1
 Coil 2 - Cylinder 2
 Coil 3 - Cylinder 3 etc.
 AEM Coil Driver Part Numbers
 - 30-2841 1 Channel
 - 30-2843 3 Channel
 - 30-2840 4 Channel
 AEM Coils
 - 30-2854 Pencil Coil
 - 30-2854-4PK Pencil Coil 4 Pack



Drawing: Ignition System - COP 2-Wire Dumb Coils with Ignitor


ECU: Infinity-6/8h

Date: 08/06/2014

Rev: A

Engineer: Nakano

Ignition System – COP 3 Wire "Smart" Coils, Infinity-6/8h



Drawing: Ignition System - COP 3-Wire Smart


ECU: Infinity-6/8h

Date: 08/06/2014

Rev: A

Engineer: Nakano

Ignition System – COP 4 Wire "Smart" Coils, Infinity-6/8h



Drawing: Ignition System - COP 4-Wire Smart

ECU: Infinity-6/8h

Date: 08/07/2014


Rev: A

Engineer: Nakano

GM_LS3_DBW_Wiring_Infinity-6_

ACCELERATOR PEDAL POSITION (APP) SENSOR



GM PIN	INFINITY PIN	WIRE COLOR	FUNCTION
A	C1-23	Purple	Sensor Ground
B	C1-69	Light Blue	Accelerator Pedal Position (APP) Sensor 2 Signal
C	C1-49	Tan	+5 Volt Reference
D	C1-24	Brown	Sensor Ground
E	C1-70	Dark Blue	Accelerator Pedal Position (APP) Sensor 1 Signal
F	C1-50	White/Black	+5 Volt Reference




INFINITY "C1" 80 PIN

THROTTLE BODY

GM PIN	INFINITY PIN	WIRE COLOR	FUNCTION
A	C1-61	Brown	Throttle Acuator Control (TAC) Motor Control - 2
B	C1-62	Yellow	Throttle Acuator Control (TAC) Motor Control - 1
C	C1-24	Tan/White	Sensor Ground
D	C1-51	Dark Green	Throttle Position Sensor 1 Signal
E	C1-50	Light Blue/Black	+5 Volt Reference
F	C1-70	Purple	Throttle Position Sensor 2 Signal



ACCELERATOR PEDAL POSITION (APP) SENSOR



THROTTLE BODY



Drawing: GM LS3 ACCELERATOR PEDAL & DBW THROTTLE BODY


ECU: Infinity-6/8h

Date: 08/04/2014

Rev: A

Engineer: Nakano

Mazda RX7 FD Wiring, Infinity 6



Drawing: 1991-2002 Mazda RX-7 FD

ECU: Infinity-6

Date: 10/01/2014

Rev: A

Engineer: Nakano

12 Month Limited Warranty

Advanced Engine Management Inc. warrants to the consumer that all AEM High Performance products will be free from defects in material and workmanship for a period of twelve (12) months from date of the original purchase. Products that fail within this 12-month warranty period will be repaired or replaced at AEM's option, when determined by AEM that the product failed due to defects in material or workmanship. This warranty is limited to the repair or replacement of the AEM part. In no event shall this warranty exceed the original purchase price of the AEM part nor shall AEM be responsible for special, incidental or consequential damages or cost incurred due to the failure of this product. Warranty claims to AEM must be transportation prepaid and accompanied with dated proof of purchase. This warranty applies only to the original purchaser of product and is non-transferable. All implied warranties shall be limited in duration to the said 12-month warranty period. Improper use or installation, accident, abuse, unauthorized repairs or alterations voids this warranty. AEM disclaims any liability for consequential damages due to breach of any written or implied warranty on all products manufactured by AEM. Warranty returns will only be accepted by AEM when accompanied by a valid Return Merchandise Authorization (RMA) number. Product must be received by AEM within 30 days of the date the RMA is issued.

UEGO oxygen sensors are considered wear items and are not covered under warranty.

Please note that before AEM can issue an RMA for any electronic product, it is first necessary for the installer or end user to contact the EMS tech line at 1-800-423-0046 to discuss the problem. Most issues can be resolved over the phone. Under no circumstances should a system be returned or a RMA requested before the above process transpires.

AEM will not be responsible for electronic products that are installed incorrectly, installed in a non-approved application, misused, or tampered with.

Any AEM electronics product can be returned for repair if it is out of the warranty period. There is a minimum charge of \$50.00 for inspection and diagnosis of AEM electronic parts. Parts used in the repair of AEM electronic components will be extra. AEM will provide an estimate of repairs and receive written or electronic authorization before repairs are made to the product.